

## Quick Checklist

### On/Off

- Use key to switch on bike and off. Take key out when not in use.
- Press and hold "M" to turn on power.
- Press and hold "M" to turn off power.
- + = increased pedal assist.
- - = decreased pedal assist
- To turn on light press and hold +
- Manually turn on rear red light by a small button under light.
- To start "walk" mode press and hold "-" the bike will start off and continue running at 6km/hr until a brake lever is pulled or you start pedalling, useful for walking beside the bike.

### Battery/Charging

- Turn off bike and charger before connecting the battery charger. Connect the charger to the battery charge port located below the handle, then plug into mains power and turn charger on. The LED will glow red, the battery is charged when LED on charger turns green.
- To take battery out, insert key, push and rotate to unlock position, this moves the locking pin to free the battery, then slide battery out.

### Tyres

- Keep tyres pumped up to approx 5 to 30 psi and adjust for level of comfort.

### Gears

- Button with + on it is to move gears from 1 to 7
- The black lever is to move gears from 7 to 1
- Mostly gears can be in the 4 to 7 range with using the assist. For hills or wind would use 3-2-1 gears with 1 for the steepest terrain.

### Throttle

- To activate the throttle press the RED button on the throttle so it stays in, pressing it again makes the button pop out and deactivates the throttle, the throttle is useful for getting the bike moving before the pedal assist starts.